
PSL backyard, Air Conditionor



- · horminal · Both On
- CARM Lock ~ ACI on, ACZ off · Shutter of ACI 1/4 Open








SW is at the eutrance of the PSL

- Nominal : on
- · (ARM Lock : Aff



PSL FFU Nominal : On, CARM LOCK : off. . Turn on/off by the circuit breaker on the pillar of the clean booth at the front of PSL room.








· FFV for the preparation area of pR area · Nomiael: On, (ARM Lock: off. · Unplug the power supply to turn it off Yarm








Air Compressor behind the PR3 chamber. · Nomial : on, CARM Lock : off. V Procédure to turn off: Close three values, SW/ off, SW2 to turn on : opposite Way










Air Conditionor around Center Area.

v MC area,

Nominal: AC, Circulator on (AKM Lock : AC, Circulator OFL





Nominal : On CARM Lock: On