2. Align the vertical line with the recoil mass line of PR2 and PRM by translating or rotating the laser leveler.

